

TECHNICAL DATA SHEET

Ki-ose 370 (Australia & NZ market) Commercial Grade Disinfectant Cleaner

Code 9185



DESCRIPTION

Ki-ose³⁷⁰ is a ready to use 2-in-1 high performance disinfectant cleaner for all hard surfaces. It provides broad spectrum disinfection in industrial, institutional, healthcare and household settings. Kills SARS-CoV-2 (COVID-19) virus, Influenza A (H1N1) and Norovirus in dirty conditions (no need to pre-clean). For aircraft, it is effective for use in galleys, on trolleys, passenger seats and tablets, luggage compartments, all surfaces in lavatories and in the cabin.



Ki-ose³⁷⁰ will not harm or damage fabrics, plastic, metals, rubber or other surfaces. It has been tested against the relevant aviation material standards. It is compliant with the requirements of the Airbus Consumable Materials list and conforms to European Norms EN Standards.

Hard surface disinfectant only. Use undiluted. Do not mix with detergents or other chemicals. Not to be used on skin. Not to be used on medical devices or other therapeutic goods.

FEATURES & BENEFITS

- Australian ARTG listed for COVID-19 claim (ARTG No.336973)
- Ready to use 2-in-1 solution, eliminating the need for pre-clean process
- Kills SARS-CoV-2 (COVID-19) Norovirus, Influenza A (H1N1) virus in 10 minutes
- Non-flammable and non-toxic formulation
- Suitable for all transport, commercial, industrial, institutional, health services, military and any essential services industry
- No damage or discolouration to any surfaces, as per both Boeing and Airbus aircraft material compatibility tests
- Good performance in the presence of organic material or soil



APPLICATION AREAS

Ki-ose³⁷⁰ can be used to disinfect and clean in the following areas

- Bathrooms – sinks, toilets, showers, tiled surfaces and any other hard surfaces
- Phones and Communication devices
- Nurseries – change tables, cleaning stations, cots, cribs
- Bodily fluids and blood spills on any hard surfaces (excludes medical devices)

TECHNICAL DATA SHEET

- Cleaning of theatre equipment and cables (excludes medical devices)
- Cleaning of tables in operating theatres (excludes medical devices)
- Intensive Care Units – Disinfecting and cleaning of all hard surfaces (excludes medical devices)
- Dental & GP Surgeries for disinfecting and cleaning surfaces including stools, tables, benches and light fittings. (excludes medical devices)
- Laboratories and clinics – wiping down of benches, cupboards

AIRCRAFT APPROVAL

- AMS 1453
- Airbus CML
- Boeing D6-7127, Boeing BSS7434
- AIMS09-00-002
- ASTM F483-09

DIRECTIONS FOR USE

SPRAY: Spray only enough Ki-ose³⁷⁰ to just cover the surface. Do not over-wet.

Wipe the surface with a cloth that is pre-wet with Ki-ose³⁷⁰ and allow up to 10 minutes contact time for disinfection. No need to re-wipe or rinse. For heavily soiled surfaces, a second application may be required. For food contact surfaces, rinse and dry afterwards. Use biocides with caution. Read the label before use. Not to be used to disinfect medical devices or other therapeutic goods.

LIQUID/WIPE: Apply Ki-ose³⁷⁰ liquid onto the wipe material until wet. Wipe and leave for up to 10 minutes to ensure complete disinfection. Wipe the surface with a clean dry lint-free cloth. It is recommended to also rinse and dry if the surfaces are in contact with food.

ORDERING INFORMATION

Code	Description	Packaging
9185/25/AU	Ki-ose 370 Commercial Grade Disinfectant	500ml
9185/42/AU	Ki-ose 370 Commercial Grade Disinfectant	5L
9185/51/AU	Ki-ose 370 Commercial Grade Disinfectant	20L
9185/64/AU	Ki-ose 370 Commercial Grade Disinfectant	200L
9185/1000/AU	Ki-ose 370 Commercial Grade Disinfectant	1000L

FIRST AID: IF ON SKIN: Wash with plenty of water. If skin irritation or rash occurs, seek medical advice/attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so and continue rinsing. If eye irritation persists, seek medical advice/attention. Wash hands after use. Do not eat, drink or smoke during use. **DISPOSAL:** Dispose of contents/container to authorised hazardous or special waste collection point in accordance with any local regulation.

WARRANTY – All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, expressed or implied, for which seller assumes legal responsibility and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or

TECHNICAL DATA SHEET

warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent. © Callington Haven Pty Ltd, contents of this document may not be used outside of this PDF without written consent by Callington
Created 28 May 2020 Date Printed 22/02/2021 1:46 PM